

# USB Printer/MFP Printer Compatibility List

Released by **LOYALTY-SECU** 20250421

<b>Zebra</b>	100% compatible with Zebra USB Printers (ideally)
<b>HP</b>	99.8% compatible with HP USB Printers (ideally)
<b>Brother</b>	100% compatible with Brother USB Printers (ideally)

Below are the models we already tested or collected from the clients. This Compatibility List is To be Continued

<b>Unsupported Models</b>	<p><b>Canon:</b>  <b>All The Canon LBP Series Printers:</b>                  For Example :                  2900/3000/3010/3018/3050/3100/3200/3210/3250//3300/3310//3410/6000/6200/6230/6300/7010/                  7100/7200/7680/8780 etc.</p> <p><b>EPSON:</b>  <b>EPSON R Series Printers:</b>                  For Example : Epson Stylus Photo                  R200/220/330/260/280/300/300M/320/330/340/380/800/R1800/1900/R2000/R2400/R2880/R3000,                  etc.</p> <p><b>Epson Stylus Series Printers:</b>                  For Example: 300/400/800/800+/1000/1500, etc.                  Epson Stylus Color Series: 880/880i/900/900G/900N/980/980N, etc.                  Epson Stylus Pro Series: 3880/4000/4800/4880/4900/5000/5500, etc.</p> <p><b>RICOH:</b>                  All Ricoh Printer Models (Excludes MP2014AD)</p> <p><b>HP:</b>                  HP1022</p>
---------------------------	---

<b>Supported Models</b>	<b>Printer Compatibility List</b>
-------------------------	-----------------------------------

<b>Brother</b>	HL1110
	HL 2040
	HL 2240DR
	HL L2300D
	HL-L2310D
	HL 5250DN
	QL700
	MFC-240C
	MFC-3820cn
	MFC-3320cn
	MFC j425w
	MFC-7420
	DCP-J100
	Brother MFC9140
	DCP-L2510D
DCP-1510 Series	
CanonScan Lide5.0	
ImageClass MF3110	
ImageClass MF3112	
ImageClass MF3220	
ImageClass MF3222	
ImageClass MF4010	
MF210/220	
G1000 Series	
G2400 MFP	
Pixma G2410	
ImageClass MF4150	
i-SENSYS MF3228	
i-SENSYS MF4018	
i-SENSYS MF4410	
i-SENSYS Fax-L150 laser printer	
L100/L150/L170	

Canon

Ip100
Ip1700
Ip2500
Ip2600
Ip3300
Ip3500
Ip3600
Ip4200
Ip4300
Ip4500
Ip4600
Ip5000
Ip6700D
Ip7500
Ip90
Ip90V
Ix5000
LBP1100
LBP2900
LBP3200
LBP3300
LBP3700
LBP 6018
LBP 6030
LBP 6040
LBP 7700c
LBP 7750c
LBP 5460
LBP 7780C
LBP 5280
LBP 7124
LBP 710c
MP110
MG3600
MP130
MP145
MP150
MP160
MP170
MP180
MP450
MP460
MP470
MP480
MP510
MP530
MP540
MP600
MP610
MP620
MP630
MP730
MP780
MP810
MP830
MP960
MP970
MP980
MX308
MX700
MX7600
MX850
LBP 6018
LBP 6030
LBP 6040
LBP 7700c
LBP 7750c
PIXMA MG2500
Pixus 990i
Pro9000
Pro9000Mark II
Pro9500
Pro9500Mark II

Epson

AL-C900
EPL-5800
EPL-6200L
EPL-N2500
LP 2500
Perfection 1270
PM-100
PM-3700C
PM-A840
PM-A840S
PM-A950
PM-G4500
PM-G5300
PM-G860
PM-T940
PM-T960
PM-T990
PX-501A
PX-5600
PX-5800
PX-A640
PX-A740
PX-FA700
PX-V780
Stylus C43UX
Stylus C45
Stylus C60
Stylus C61
Stylus C65
Stylus C66
Stylus C67
Stylus C90
Styluscolor 670
Stylus CX2900
Stylus CX3500
Stylus CX3700
Stylus CX3810
Stylus CX3900
Stylus CX4700
Stylus CX4800
Stylus CX4900
Stylus CX5600
Stylus CX9300F
Stylus photo1270
Stylus photo2200
Stylus photo830
Stylus photo915
Stylus TX210
Stylus R310
Stylus R320
Stylus RX510
Stylus RX530
LS300
LQ310
L395
L396
L495
L606
L3110
L800
L805
L850
L1455
L1800
L3110
L3150
L3153
L3160
L3210
L3250
L3251
L3260
L4150

L4160
L4168
L4166
L4260
L5190
L5290
L6161
L6171
L6191
L6270
L6490
L8160
L8180
L14150
L15150
L15160
TX210
Stylus RX590
Deskjet 1125C
Deskjet 1180C
Deskjet 3745
Deskjet 5652
Deskjet 640C
Deskjet 830C
Deskjet 920C
Deskjet 2130
Deskjet D2360
Deskjet D2460
Deskjet 3050
Deskjet D3745
Deskjet D4160
Deskjet D4260
Deskjet F2200
Deskjet F300
Deskjet F340
Deskjet F350
Deskjet F370
Deskjet F379
Deskjet F380
Deskjet F4185
LaserJet 1000
LaserJet P1006
LaserJet P1007
LaserJet P1008
LaserJet 1010
LaserJet 1015
LaserJet 1018
LaserJet 1020
LaserJet Pro CP1025
LaserJet Pro M402
LaserJet Pro P1102
HP M1132MFP
LaserJet M1132
LaserJet 1160
Laserjet M1319
LaserJet p2055dn-
LaserJet Pro M1132
LaserJet 2420
LaserJet 2600n
LaserJet 3015
LaserJet 3030
LaserJet 3050
LaserJet 3050z
LaserJet 3330
LaserJet 3380
Laserjet 3390
LaserJet 1005
Officejet 4255
Officejet 4500
Officejet 5510
Officejet 5600
Officejet 5610
Officejet 6210

HP

	OfficeJet 6950
	Officejet 7210
	OfficejetG85
	OfficejetL7380
	Business inkejet 1200
	Photosmart C3180
	Photosmart C4200
	PS 2610
	PS 3110
	PS 3210
	PS 3310
	PS 335
	PS 7830
	PS 8030
	PS A310
	PS C3180
	PS C5280
	PS P1000
	PS C1210
	PS C1315
	PS C1350
	PS C1402
	PS C1410
	PS C1510
	PS C1610
	PS C2210
	PS C2410
	PS C2510
	Scanjet4200C
	Scanjet4370
	Color láserjet 1600 printer
	Color LaserJet 4600 Printer series
<b>Lexmark</b>	E120
	P4350
	P6250
	X1270
	X2250
	X2650
	X3350
	X3470
	X3550
	X4270
	X5150
	X5470
	X5495
	X6170
	X7350
	X8350
	Z1350
	Z43
	Z55
	CS417dn
Z705	
CLP-365 printer	
<b>Samsung</b>	ML1640
	ML1670
	ML-1710
	ML-1750
	ML-2010
	SCX 4016
	SL-M2070F
	CLX-3175
	ML-2165
	Color laser printer clo-680nd
	SCX 4500
	Samsung SCX4300
	Samsung SCX3405F
SCX-3200 NOT SUPPORT	
ZP888	
ZD400	

<b>Zebra</b>	GK420
	ZT400
	ZD888-CR/GK888T
	ZDesigner ZD420-300dpi
	ZDesigner ZT410
<b>Dell</b>	1250c laser printer
<b>FUJI XEROX</b>	Phaser 3010 printer
	DocuPrint CM305 df
<b>Xprint</b>	Xprinter XP-365B
<b>Kyocera</b>	Kyocera ECOSYS P2335d
	Kyocera Ecosys M6030cdn
<b>Pantum</b>	Pantum M6500 Series
<b>DYMO</b>	Thermal label printer
<b>Avision</b>	MF3230
<b>BenQ</b>	CM3000
	CM3500
	CM3500
<b>IBM</b>	Infoprint1332
<b>Konica Minota</b>	MC-2430DL
	Pro1350W page
<b>OKI</b>	B4350
	MICROLINE 5460HU2

**Remarks:**

As there are so many USB printers in the market with different brands, we are unable to test all the models among them.  
**LOYALTY-SECU** Print Servers are compatible with any standard USB Printer which with the "RAW" Data format under ideal conditions.